



PIR Motion Sensor Infrared Anti-Theft Alert System

The Wolf PIR alarm monitors your fishing area with the help of a built-in infrared sensor and gives a direct signal on the device if a stranger or an animal should approach unnoticed day or night. If something is approaching your area a bright LED flashes. There are 3 settings of sensitivity available, Low, Medium and High. The PIR can also be paired to the Wolf PIR remote sounder or the Wolf Icon HUBB or Qr receivers.

Inserting Batteries

To insert batteries use screwdriver provided and open the 2 screws on the battery compartment. When inserting 3 new AAA batteries always replace all of them. When PIR is not going to be used for a while it is recommended to remove batteries in case of leakage.

Power On

When the PIR is turned off, Press Power Button and hold for 4 seconds.

Power Off

From any state press and hold Power Button for 4 seconds. Release Power Button.

Battery Level Indication

Good battery level shows green, OK battery level shows yellow and bad battery level shows red.

Pairing

When the receiver is ready for pairing, press and hold the Power Button for 8 seconds. The LED will pulse blue to indicate the PIR is ready for pairing. Release Power Button to initiate pairing.

Arming Sequence

After power on the PIR will start an arming sequence, with a flashing of the LED in the selected alert colour. The flashing gets faster as the sequence completes. This gives the user roughly 15 seconds to set up the device and move out of the detection zone without triggering an alert. After the sequence has completed, the PIR will start detection.

Detection Range

Local 1m / Mid range 3m / Long range 8-10m.

Sensitivity Settings

3 settings of sensitivity available: Low, Medium and High. A double press of Power Button to cycle through sensitivity levels. Each setting is represented by a different LED flash sequence.

Low Sensitivity: 1 x Green Flash.

Medium Sensitivity: 2 x Green Flash.

High Sensitivity: 3 x Green Flash.

Alert Colour

Single presses of Power Button will allow the alert colour to be changed. The current alert colour will be previewed on the LED. Further single presses of Power button will cycle through available colours, and a stealth mode with no LED indication.

LED Colours

Red, Green, Blue, Cyan, Yellow, Magenta or White.

LED Modes

Detection Only - Flashes alert colour & Standby.

RF Range

2km approx.

Warranty 3 Years with 4th Year FREE on registration

COMPLIANT TO:

The ICON Series has been designed and developed and is made in Britain.
Safety EN 62368-1
RED 2014/53/EU
ROHS