

5. 4 LED indicators , first indicate 0~25%, second, 2 lighting LEDs indicate 25-50% capacity, 3 lighting LEDs indicate 50-75% capacity, 4 lighting LEDs indicate 75-100% capacity. LED indicators will remain on and stop flashing when Powerbank is fully charged.

WARNING

- **DO NOT** attempt to open or dismantle the product.
- **DO NOT** subject the Powerbank to naked flames or extreme heat.
- **DO NOT** stand on or otherwise apply pressure to the Powerbank.
- **DO NOT** allow children to play with the Powerbank.

Whilst the device will charge in high temperatures please ensure the device never sits in direct sunlight for a prolonged period of time as the charger has a maximum temperature of 45°C (113 °F).

- Stop using this Powerbank if it occur expansion or break down, and contact local distributor.

Charging Status/LED Indicators	0% ~25%	25% ~50%	50% ~75%	75% ~99%	100%
1st LED Indicator	Flashing Blue	Solid Blue	Solid Blue	Solid Blue	Solid Blue
2nd LED Indicator	OFF	Flashing Blue	Solid Blue	Solid Blue	Solid Blue
3rd LED Indicator	OFF	OFF	Flashing Blue	Solid Blue	Solid Blue
4th LED Indicator	OFF	OFF	OFF	Flashing Blue	Solid Blue

Note

1. The full charging time is only for your reference, please refer to actual operation.
2. High quality guarantee, using A-grade Li-ion battery cell for this Powerbank , please be assured use.
3. Please using the matched charging cable according to your mobile phone and digital product.
4. It will cause slight heating due to electric consumption when charging and discharging, it's normal phenomenon.
5. Please store this Powerbank in a cool and dry place, if do not use for a long period, please fully charged this Powerbank at every 6 months interval.
6. Please find our suggestion to choosing regular 5V-2A charger to charge this charger, in order to ensure the stability of this product usage.
7. Please do not put together this Powerbank with metal or tool items, in order to avoid scratching surface or damage.

WOLF INTERNATIONAL LTD

Suite 1, 284 Warley Hill, Great Warley,
Brentwood, Essex CM13 3AB
E: sales@wolfint.co.uk | T: +44 (0) 333 366 8888
E: support@wolfint.co.uk
www.wolfint.co.uk



Product Code: WFPT003




LPB-260 BIVVI LIGHT POWERBANK

 **ENGLISH**

Thank you for purchasing this LPB-260 Bivvi Light / Powerbank. Please read the manual carefully before use, and keep it for reference in the future.



For language translations of LPB-260 Bivvi Light Powerbank instructions visit www.wolfint.co.uk



Specifications:


Capacity	2600mAh
Micro Input	DC 5V 2A Max
USB Output	DC 5V 2A Max
Product Size	133.5*35*35 / mm
Product Net Weight	116.0/g
Full Charging Time	2 hours
Operation Temperature	0~45(°C)
Battery Type	18650
Flashlight	1W
Side LED Light: White	0,5W*10
Side LED Light: Red	0,5W*4

Accessory List:

User Manual
 Charging Cable
 LPB-260 Bivvi Light/Flashlight/Powerbank


Product Features:

- **IP66:** Rainproof, dustproof, shockproof, designed for outdoor sport use. It will be very helpful when travelling, climbing, swimming, bicycling.
- **2600mAh capacity:** 4 blue indicators for power status.
- USB Output*1; Micro Input*1.
- There are two magnets on the top of product, and one magnet on the top and bottom side. Please pay attention to the magnet mark when using.
- **Safe Use:** Short circuit protection, over-discharging protection and over-charging protection are designed in PCBA.
- Bright LED torch, on the side with 10 white LEDs and 8 red LEDs.
- Front and back side with silicone protection.
- Button with multifunction operation.



1. USB Output: DC 5V 2A Max
2. Micro Input: DC 5V 2A Max
3. 4 indicators for power status
4. 10 white LEDs and 4 red LEDs
5. Button with multifunction operation
6. Magnet placement
7. Magnet placement
8. 30 meter long distance torch
9. PC semitransparent tube
10. Shockproof silicone cover
11. Plastic cement

Operating instructions:



1. Connect the charger by provided cable of USB-A port and connect your Powerbank the end of cable for charging the Powerbank. Please kindly choose the charger which voltage between 5.0V-5.5V.
2. Charging device: Open the cap of the Micro Input, connect the USB-A end to one of the output ports on the Powerbank. Powerbank will charge your device automatically once the cable is connected. The Powerbank will shut off in 32 seconds when no device is being connected.
3. Charging Powerbank: Open the cap of the USB Output, connect the larger end of the the USB cable provided to your PC or (a USB power adapter not provided) and the Micro USB end to Powerbank. (Notice: For charging Powerbank, it doesn't support charging and discharging at the same time).
4. **Button operation:** Press once to check battery status;

Side LED lights: Double press button to turn on LED in white light (Long press the button to adjust the brightness). Press again to turn on LED in red light (Long press the button to adjust the brightness). Press once again to white light strobe, twice press to red light strobe, and again white and red light strobe by turns. Press once to turn off LED (In strobe status, press button for 3 seconds also can turn off LED).

Flashlight: when side light off, press the button for 3 seconds to turn on flashlight, press again to strobe, once again to SOS, to turn off flashlight, press once or for 3 seconds